

QMI

QUALITY MONITORING INSTRUMENTS LTD

TRIPLEX™ ATMOSPHERIC OIL MIST DETECTION SYSTEM

INSTALLATION AND OPERATIONS MANUAL



SPECIALISTS IN OIL MIST DETECTION

QMI TRIPLEX™ ATMOSPHERIC



Triplex™ Atmospheric

Oil Mist Detection System

This Manual provides information to assist with the Installation,
Testing and Maintenance of all components relating to the
QMI Triplex™ Atmospheric Oil Mist Detection System

Triplex™ Atmospheric Oil Mist Detection System

INTRODUCTION

QMI TRIPLEX™ Atmospheric Oil Mist Detection Systems have been providing an early warning to hazardous levels of oil mist in confined areas for over 35 years, in environments such as: Engine Rooms, Test Cells and Hydraulic pack areas – anywhere where the increasing density of an oil mist adjacent to a hot working surface could cause a fire and personal injury.

If installed and operated correctly, your **TRIPLEX™ Atmospheric Oil Mist Detection System** can measure an oil mist between 3 and 10 microns from up to 12 discrete areas you intend to gather data from and monitor.

We pride ourselves on the fact that our equipment provides a fast response to a potentially escalating situation, without providing ‘false’ alarms, and we would encourage you to follow the processes in this Manual to ensure your system is installed, tested and operated effectively.

Our systems have been tested and Type Approved by the following:



Additionally, QMI also manufacture a **MULTIPLEX™ Atmospheric Oil Mist Detection System** for installations where up to three points of measurement are required, and also an **Engine Crankcase Oil Mist Detection System** for similar diesel applications where engine conditioning data is employed to assist with avoiding unnecessary engine wear and resulting expensive repairs, along with the safety aspects as previously described.

For more information, please see our website: www.oilmist.com

© 2022 Quality Monitoring Instruments Ltd.

Errors and omissions excepted.

As we strive to improve our service and products specifications may change or vary.

Contents

SECTION 1 \ PRODUCT DESCRIPTION AND SYSTEM OVERVIEW

| | | |
|-----|--|-------------|
| 1.1 | About the QMI System | Page 02 |
| 1.2 | Key Components | Page 02 |
| 1.3 | TRIPLEX™ MONITOR CENTRAL MONITORING UNIT (CMU) | Pages 03-06 |
| 1.4 | Atmospheric Sensor with Articulated Joint | Pages 07-08 |

SECTION 2 \ INSTALLATION GUIDELINES

| | | |
|-----|---------------------------------------|---------|
| 2.1 | General Arrangement - Wiring Option 1 | Page 10 |
| 2.2 | General Arrangement - Wiring Option 2 | Page 11 |

SECTION 3 \ SENSORS – POSITIONING AND LOCATION

| | | |
|-----|---|-------------|
| 3.1 | Number of Sensors required | Page 14 |
| 3.2 | Location of Sensors | Page 14 |
| 3.3 | Positioning of a Sensor | Pages 15-16 |
| 3.4 | Positioning of a Sensor - Best Practice | Page 17 |

SECTION 4 \ CABLING AND WIRING

| | | |
|------|--|-------------|
| 4.1 | Cabling Specifications | Page 20 |
| 4.2 | Fault Alarm | Page 20 |
| 4.3 | Earthing of Sensors | Page 20 |
| 4.4 | Wiring Description | Page 21 |
| 4.5 | Wiring of Socket | Pages 22-23 |
| 4.6 | Wiring for System Layout | Pages 24-25 |
| 4.7 | Wiring Option 1: Individual Wiring for Sensors | Page 26 |
| 4.8 | Cable Details For Connection From Atmospheric Sensors | Page 27 |
| 4.9 | Cable Details For Connection From Atmospheric Sensors to 3-Way PCB | Page 28 |
| 4.10 | Wiring Details From TRIPLEX™ Monitor to 3-Way PCB | Page 29 |
| 4.11 | Wiring Details From The 3-Way PCB | Page 30 |
| 4.12 | Alarm Outputs And Alarm Level Wiring | Page 31 |
| 4.13 | TRIPLEX™ 4-20mA Analogue Data Logger Output | Page 32 |

Contents

SECTION 5 \ SETTING UP THE SYSTEM

| | | |
|-----|----------------------------------|---------|
| 5.1 | Setting up Sensors | Page 34 |
| 5.2 | Changing the number of Sensors | Page 35 |
| 5.3 | Isolating or restoring a Channel | Page 36 |
| 5.4 | Test sequence | Page 37 |

SECTION 6 \ OPERATING THE SYSTEM

| | | |
|-----|--|-------------|
| 6.1 | TRIPLEX™ Pre-Power on Check | Pages 40-42 |
| 6.2 | Operating | Page 43 |
| 6.3 | Setting and Changing Alarm Levels | Page 44 |
| 6.4 | Operation of Alarm Relays | Page 45 |
| 6.5 | Response to an Alarm | Pages 46-47 |
| 6.6 | Fault Directory | Pages 48-49 |
| 6.7 | Fuses | Page 50 |
| 6.8 | Security Key Switch | Page 50 |
| 6.9 | Transistors TR1, LEDs and Fuses on PCB | Pages 51-52 |

SECTION 7 \ MAINTENANCE

| | | |
|-----|------------------------------|-------------|
| 7.1 | Maintenance Procedure | Page 54 |
| 7.2 | Lens Cleaning Procedure | Pages 55-56 |
| 7.3 | Replacing Fan in Sensor | Page 57 |
| 7.4 | Maintenance Kit | Pages 58-59 |
| 7.5 | Suggested Maintenance Plan | Page 59 |
| 7.6 | Replacement Parts and Spares | Pages 60-61 |

SECTION 8 \

| | |
|----------------------|---------|
| RETURNS PROCEDURE | Page 64 |
| CONTINUOUS SUPPORT | Page 65 |
| PRODUCT REGISTRATION | Page 66 |

SECTION 1

PRODUCT DESCRIPTION AND SYSTEM OVERVIEW

| | | |
|-----|--|-------------|
| 1.1 | About the QMI System | Page 02 |
| 1.2 | Key Components | Page 02 |
| 1.3 | TRIPLEX™ MONITOR CENTRAL MONITORING UNIT (CMU) | Pages 03-06 |
| 1.4 | Atmospheric Sensor with Articulated Joint | Pages 07-08 |



SECTION 1 \ PRODUCT DESCRIPTION AND SYSTEM OVERVIEW

1.1 ABOUT THE QMI SYSTEM


QMI TRIPLEX™ Atmospheric Oil Mist Detection Systems have been providing a fast response to situations where hazardous levels of oil mist in confined areas, such as in Engine Rooms, Test Cells and Pump Rooms, could cause a fire and endanger life.

Oil Mist is measured using the principle of light scatter (nephelometry) across a series of Atmospheric Sensors. A signal, which is proportional to the oil mist in the sample, is sent simultaneously and continuously to the TRIPLEX™ Monitor (CMU) every 500 milliseconds.


1.2 KEY COMPONENTS

There are two components which make up the operating elements of the system:

- **TRIPLEX™ Monitor (CMU)**
- **Atmospheric Sensor with an Articulated Joint** (up to a maximum of 3 Sensors per Monitor)




TRIPLEX™ Monitor (CMU) Part No. Q01T



Atmospheric Sensor With Articulated Joint
Part No. Q10C

Additionally, should your installation require it, as an optional wiring extra, an (unboxed) 3-Way PCB can be added into the configuration in a Junction Box, (supplied by others).



3-WAY PCB Part No. Q01T06

1.3 TRIPLEX™ MONITOR CENTRAL MONITORING UNIT (CMU)


The layout of the QMI TRIPLEX™ Monitor (CMU) is designed for rapid monitoring, ease of use and simple functionality.

The Monitor is made up of three principal parts:

a) Display Panel

The TRIPLEX™ Display Panel is shown below.

The panel is mounted on a hinged bezel which is secured to the enclosure by 4 x M6 captive socket head screws. Releasing these screws and hinging back the Display Panel allows the access to the TRIPLEX™ PCB and the Relay Board within.




1.3 TRIPLEX™ MONITOR CENTRAL MONITORING UNIT (CMU)

b) TRIPLEX™ MONITOR PROCESSOR BOARD - Version 3.2 (Part No. Q01T08)

The back of the Display Panel carries the TRIPLEX™ MP3 Processor Board (Part No. Q01T08), Binary Switch and Flash Chip.

The TRIPLEX™ Monitor Processing Board - Version 3.2. (Part No. Q01T08) is held on to the panel with 6 x M4 Cheese Head screws.




c) Relay Board with PSU (Part No. Q01T05)

Mounted on the Relay Board is a Power Supply Unit (PSU); Fuses; TR1 resistor (Cap R); Alarm relays and termination sockets.


NOTE:

A Mains isolator is not fitted to the Monitor. QMI recommend that one is fitted to prevent power interruption to the system.



1.3 TRIPLEX™ MONITOR CENTRAL MONITORING UNIT (CMU)

Physical and technical properties of the TRIPLEX™ CPU are as follows:



THE DISPLAY PANEL

The Display Panel is mounted on a hinged bezel which is secured to the enclosure by 4 x M6 Cheese Head screws. Releasing these screws allows access to the TRIPLEX™ PCB and the Relay Board within.

TRIPLEX™ MONITOR PROCESSOR BOARD - Version 3.2. (Part No. Q01T08)

The back of the Display Panel carries the TRIPLEX Monitor Processor Board - Version 3.2. (Part No. Q01T08), with the Binary Switch and Flash Memory Chip which is attached to the display, (the Monitor faceplate) by 5 x M4 Cheese Head screws.

RELAY BOARD with PSU (Part No. Q01T05)

The Relay Board consists of a switch mode Power Supply Unit (PSU) mounted on a PCB. The PCB holds the fuses, the transistor TR1 (Part No. Q0111) and the terminal plugs and carries the alarm relays.

1.3 TRIPLEX™ MONITOR CENTRAL MONITORING UNIT (CMU)

The Technical Specifications of the TRIPLEX™ CMU are as follows:

| | |
|---|---|
| POWER SUPPLY | Nominally 110/240V AC 50/60 Hz |
| MAXIMUM POWER CONSUMPTION | 100W |
| MAXIMUM SAMPLING CHANNELS | 3 |
| CYCLE TIME | 500 milliseconds simultaneously on all channels |
| SYSTEM OUTPUTS - RELAYS | All relays fitted with maximum change over contacts voltage rating 110V@8A to 240V 5A |
| Main alarm | Normally energised with 1 set of change over contacts |
| Early warning alarm | Normally energised with 1 set of change over contacts |
| Shutdown alarm NOT INCLUDED IN TEST SEQUENCE | Normally de-energised with 1 set of change over contacts. |
| Fault alarm | Normally energised with 1 set of change over contacts |
| OPERATING TEMPERATURE | 5-70 °C Monitor, Sensor and Fan Unit |
| TRIPLEX™ - DIMENSIONS (mm) | 280 x 230 x 126 |
| TRIPLEX™ - WEIGHT (kg) | 5.2 |
| MONITOR, SENSOR AND FAN UNIT | Sealed to IP65 |
| FEATURES | Continuous self-monitoring fault diagnosis. Manual test facility of all functions except functional shutdown (e.g. hydraulic pack). |
| OPTIONAL | Individual Shutdown / 4-20mA output for up to 3 individual alarms or data-logging of alarms |

SENSOR DETAILS:

| | |
|--------------------------|---|
| SENSOR - DIMENSIONS (mm) | 359 x 113 x 73 |
| SENSOR - WEIGHT (kg) | 2.30 |
| MAXIMUM DISTANCE | Maximum cable length between Sensors and Monitor is 100 Metres. (For lengths longer than 100 Metres contact QMI.) |

FUSE ARRANGEMENTS:

| | |
|---------------------|---------------------------------|
| Fuse FS1 - Internal | Sensor interface 1.25A |
| Fuse FS2 - Internal | 12V DC Fan Failure Supply 400mA |
| Fuse FS3 - External | 110V/240V 3.15A Anti-Surge |

1.4 ATMOSPHERIC SENSOR WITH ARTICULATED JOINT (Part No. Q10C)

The Sensor operates using the principle of light scatter (nephelometry). The power and signal are transmitted to and from the Monitor through a single cable sending a timed analogue signal.

All Sensors sample simultaneously and continuously every half-second (500 milliseconds.)

The assembled Sensor comprises of:

- a) Sensor
- b) Articulated Joint

a) SENSOR

Inside the Sensor unit are sensing lenses, an integral fan and PCB. Power is supplied to the 12V fan by a single cable, which is connected to the Monitor or to the Monitor via a Junction Box. The fan draws the samples of air past the Sensors and exhausts through the outlet ports. In the front of the Sensor unit are the air intake louvres and an LED, which shows green when the fan is working. The electronics are mounted on the back of the chamber casing and are protected by the cover sealed to IP65. At the back of the unit is the multi-purpose power and signal connector. Next to this connector is the mounting spigot.

b) ARTICULATED JOINT

The Articulated Joint is fitted to the bulkhead or deckhead allowing the Sensor to be positioned facing the flow of air in the chamber being monitored. The Sensor is fitted to the Articulated Joint with 4 screws, which can be removed if, and when, the Sensor lenses require cleaning or the fan changing.



Part No. Q10C Atmospheric Sensor with Integral Fan,
Mating Connector and Articulated Joint

NOTE:


The integral fan is interchangeable without calibrating the fan, which can be purchased separately. They are considered consumable so are not covered by warranty.

1.4 ATMOSPHERIC SENSOR WITH ARTICULATED JOINT (Part No. Q10C)

The physical dimensions of the Sensor are as shown below, (not to scale.)


SENSOR

Weight: 1.5kg




ARTICULATED JOINT

Weight: 0.8kg



SENSOR and ARTICULATED JOINT ASSEMBLED

Weight: 2.3kg



Dimensions in mm

SECTION 2

INSTALLATION GUIDELINES

- 2.1 General Arrangement – Wiring Option 1
- 2.2 General Arrangement – Wiring Option 2

Page 10

Page 11



2.1 GENERAL ARRANGEMENT - WIRING OPTION 1

There are two possible options for installing a TRIPLEX™ Oil Mist Detection System:


OPTION 1 - For up to a maximum of 3 Sensors all individually wired (as shown below) or

OPTION 2 - Which uses a 3-Way PCB (unboxed) as shown on the next page.

The relevant option will depend on your installation requirements.


WIRING OPTION 1 – FOR 1-3 SENSORS - ALL WIRED INDIVIDUALLY

TRIPLEX™ Monitor (Part No. Q01T)



2.2 GENERAL ARRANGEMENT – WIRING OPTION 2

For wiring 2 to 3 Sensors to the Monitor from the Plant Room with a single cable, the cable from the Monitor is wired into a PCB. The PCB is mounted in a Junction Box, (not supplied by QMI) and individual cables are run to each Sensor as shown below.



SECTION 3

SENSORS – POSITIONING AND LOCATION

| | | |
|-----|---|-------------|
| 3.1 | Number of Sensors Required | Page 14 |
| 3.2 | Location of Sensors | Page 14 |
| 3.3 | Positioning of a Sensor | Pages 15-16 |
| 3.4 | Positioning of a Sensor - Best Practice | Page 17 |



3.1 NUMBER OF SENSORS REQUIRED

When deciding on the number of Sensors required to monitor an area or system, several factors need to be considered. How many failure points are there? Which way is the air flowing past these failure points? Is there a large extractor operating in the space? In large engine rooms, we have fitted up to 24 Sensors to monitor the atmosphere, but in smaller hydraulic power pack rooms, possibly only one or two Sensors would be required to give adequate Sensor coverage. When deciding on the number of Sensors to be fitted in an area, good engineering practice and an understanding of the air flow in that area should be used.

NOTE: Sensors CANNOT be used in any space with a HAZARDOUS ZONE classification, such as certain pump rooms or open deck areas.

3.2 LOCATION OF SENSORS

Please follow the guidelines below to get the best results.

We recommend using a smoke test aerosol or smoke generator to ascertain the way the air flows over the machinery. (See also section 3.3.) Normally, air will move toward ventilation extractors or the turbo charger, therefore the Sensor must be placed in the air stream as close as possible to the machinery.

The Sensor comes with a fixing flange which is welded on to the Articulated Joint. We suggest the length of the cable that runs to the Sensor is longer than required to enable the Sensors to be moved at a later date if deemed necessary.

To confirm that the Sensors are correctly positioned you should carry out the following test; Wait until the engines, ventilation and other machinery are fully operational, then once again use your smoke test aerosol or smoke generator to prove the Sensors are correctly positioned. The Sensor should be rotated until positioned mid-airflow as indicated by the movement of smoke.

NOTE: Always place the Sensor in a position so that it can be easily maintained as the Sensors should be cleaned regularly.

3.3 POSITIONING OF A SENSOR

We discuss below how the movement of oil mist in the atmosphere responds in working environments and suggest how the placement of Sensors in an optimum position is determined by the flow of air. The Sensors may have to be adjusted when setting up the system, (or even later), when any structural alterations are made or when machinery changes or more powerful fans are introduced within the area.

There are so many variables in the detection of oil mist in the atmosphere that it is by no means an exact science. Common sense has a part to play when positioning Sensors.

3.3.1 HOW MUCH DOES THE SENSOR DRAW?

It pulls through 23 cubic feet/min or 0.65m³/min.

3.3.2 WHAT IS THE DETECTING RANGE?

There is no detecting range for the Sensor. The Sensor uses its internal fan to draw in air, which is then tested for oil mist. Three sensor devices inside the Atmospheric Sensor measure backscatter of light from oil mist (smoke/steam) particles drawn into the Sensor, and dirt on the lenses.

3.3.3 WHAT ARE THE FACTORS THAT DETERMINE THE POSITIONING AND NUMBER OF SENSORS NEEDED?

Four factors determine good positioning and number of Sensors. These factors should be considered together, and a smoke generator is a good way to observe air movement and test positioning of the Sensors.

1/ Size of room or chamber (e.g. hydraulic pack area or engine room)

The fan in the Sensor has a through-put of 0.65m³ per minute. In a large room more Sensors will allow a faster response. Also, dispersal of oil mist will be greater in a larger space and will require more careful positioning of the Sensors in the path of airflow.

2/ Air circulation

In addition, the movement of air affects how many Sensors should be installed. If a room has only one vent then the Sensor placed near this vent will be able to sample air extracted from the room. However, if there is more than one vent or point of extraction a Sensor is best placed in each path of air being drawn towards each of the vents.

This is why a smoke test aerosol or a smoke generator is used to ensure the Sensor points towards the potential source of oil mist. The Sensor should be installed with the intake louvres facing the path of the smoke as shown by the smoke generator. The smoke generator will also show any eddies or paths that the air may follow in the chamber which is important to ensure that Sensors are correctly positioned.

In hydraulic pack areas there should be a Sensor between each extractor and the packs which normally means 2 to 3 Sensors, especially if the pack is in the engine room. This should be borne in mind with any areas being monitored.

3/ Proximity to potential source of oil mist


A Sensor should be placed downstream of the airflow around a potential source of oil mist (e.g. hydraulic pump). The closer a Sensor is to the machinery, the faster the response time should be.

4/ Number of potential sources of oil mist

A fourth factor is the number of potential sources of oil mist. To make it easier to determine the source of oil mist, each piece of machinery or potential oil mist source should have a Sensor installed immediately downstream of the air flow to ensure the fastest response possible.


In an engine room several Sensors are needed but the exact location will vary according to the air flow.

Some examples of Sensor installations and positioning.




3.4 POSITIONING OF A SENSOR – BEST PRACTICE

In order to assist with the best positioning of a Sensor, QMI have developed an Articulated Joint, which is supplied with the Sensor.



The articulation available through use of this Joint allows the Sensor to be positioned mid airflow, in any direction.



BEST PRACTICE

Until the system is operational, to avoid contamination of the lenses of the Sensor after installation, cover Sensors with a plastic bag. This will prevent paint or other materials dirtying or damaging the lenses or blocking the Sensor louvres and fan. This outcome permanently damages the sensors and may require them to be returned to QMI for repair.

When oil mist detection system is in operation:

- Do not conduct painting in the same space as the Sensors
- NEVER cover the Sensors


When Sensors are installed but not in operation:

- Keep Sensor(s) sealed in a plastic bag

SECTION 4

CABLING AND WIRING

| | | |
|------|--|-------------|
| 4.1 | Cabling Specifications | Page 20 |
| 4.2 | Fault Alarm | Page 20 |
| 4.3 | Earthing of Sensors | Page 20 |
| 4.4 | Wiring Description | Page 21 |
| 4.5 | Wiring of Socket | Pages 22-23 |
| 4.6 | Wiring for System Layout | Pages 24-25 |
| 4.7 | Wiring Option 1: Individual Wiring for Sensors | Page 26 |
| 4.8 | Cable Details For Connection From Atmospheric Sensors | Page 27 |
| 4.9 | Cable Details For Connection From Atmospheric Sensors to 3-Way PCB | Page 28 |
| 4.10 | Wiring Details From TRIPLEX™ Monitor to 3-Way PCB | Page 29 |
| 4.11 | Wiring Details From The 3-Way PCB | Page 30 |
| 4.12 | Alarm Outputs And Alarm Level Wiring | Page 31 |
| 4.13 | TRIPLEX™ 4-20mA Analogue Data Logger Output | Page 32 |



4.1 CABLE SPECIFICATIONS

For the following connection we RECOMMEND THE MINIMUM TYPE AND SIZE as follows:

Halogen free instrumentation, control and communication cable for fixed installation in ships or equivalent appropriate specifications for application.

Conductor: Standard copper conductor, annealed, IEC228 CLASS2

Insulation: According to appropriate standards

Pairs: Two core twisted cable size 1 x 4 x 0.5mm² or 0.75mm²

Stranding: Pairs stranded together

Screening: Braid of Annealed Copper Wires. Filler tape under braid.

| CONNECTION | NUMBER OF CONDUCTORS AND CROSS SECTION (n x mm ²) |
|-------------------------------|--|
| Monitor to Alarms or Shutdown | 4 x 2 x 0.5mm ² |
| Monitor Power | 3 x 1.5mm ² rating minimum 3A LNE not twisted |
| Monitor to Sensors | 4 x 2 x 0.5mm ² for lengths under 100m 4 x 2 x 0.75mm ² for lengths over 100m |

Example supplier: Helkama of Finland (LKM – HF for 3 x 1.5 power cable) and RFE – HF for 4 x 2 x 0.5mm² twisted connection cables.

4.2 FAULT ALARM

When fault alarm is activated, the Monitor will still process information. On activation, the lights will flash: Green, Amber or Red status and F1, F2 or F3 will be indicated on the display.

4.3 EARTHING OF SENSORS

The screen is normally connected to Pin 5. No earth should be made at the Sensor end as this could result in ground loops. Earths made to any other point from the screen wire between Monitor and Sensor will be ineffective and could cause additional interference.

4.4 WIRING DESCRIPTION

The wires are terminated into screw type plugs. These plug into the connectors on the TRIPLEX™ Relay Board with PSU fitted. (Part No. Q01T05).

They have to be plugged in THE CORRECT WAY ROUND. (See photograph of Relay Board on Page 24.)

4.4.1 WIRING FOR POWER SUPPLY 110/240V AC

The Mains connector is a 3-pin with Live, Neutral and Earth. On the Power Supply Board this is marked L, N+.

Cable is a 3 core of 1.5mm² and can be sourced from Helkama; part number LKM – HF 3 x 1.5.

4.4.2 WIRING FOR SENSORS

The Sensors are wired using 3 twisted-pair cable. Each connector is wired left to right and numbered 1 to 6. The cable specification is 3 twisted pair of 0.5mm² for distances under 100 metres or 3 twisted pair of 0.75mm² where distance is over 100 metres.

This cable can be sourced from Helkama, part number RFE – HF 4 x 2 x 0.5mm² or 4 x 2 x 0.75mm².

Terminal 1 = Sensor supply +

Terminal 2 = Sensor signal

Terminal 3 = Sensor supply common

Terminal 4 = Sensor signal common


Terminal 5 = Drain wire/screen

Terminal 6 = Fan 12V DC supply

The cable to use for wiring of alarms can be the same as used for wiring of air Sensors. If you intend to use all four alarms you will need a 4 twisted pair cable.

PLEASE NOTE: As we do not know what diameter of cable will be used our Monitors are supplied with blind grommets.

4.5 WIRING OF SOCKET



| | |
|----|--|
| 1/ | RETAINING RING |
| 2/ | CONNECTING BLOCK WITH TERMINALS |
| 3/ | BARED AND TINNED WIRES |
| 4/ | MAIN HOUSING OF SOCKET |
| 5/ | CABLE LOCKING SCREW |
| 6/ | MAIN SECURING THREAD TO HOLD SOCKET TO PLUG |
| 7/ | 24mm ADHESIVE HEAT SHRINK SLEEVING (Not supplied by QMI) |

ASSEMBLY INSTRUCTIONS

- 1/ Strip back about 125mm of outer sheathing of cable and separate the wires. Then tin the ends of wires and the drain/wire screen being used.
- 2/ Assemble socket on to wire in the sequence shown in illustration. By passing wires through parts **4** , **5** , **6** and **7**
- 3/ Wire bared wires and screen to correct numbered terminals of Part 2. Numbers are shown by the terminals. See section 4.4.2., page 21.
- 4/ Reassemble and lock with part number **1**
- 5/ Pull heat shrink **7** over first part of **4** and wire to main cable and then shrink in the appropriate way.

4.5 WIRING OF SOCKET

IMPORTANT NOTES

- 1/** The Terminal connectors on the TRIPLEX™ Relay Board are numbered in sequence from left to right – 1, 2, 3, 4, 5, 6.
- 2/** The Connector drawing (see Page 22) shows the terminations of the twisted pairs and their location on the connector and PCB in the WIRING TERMINATION sequence 1, 3, 2, 4, 5, 6.
- 3/** The 'Common Supply' wires **MUST NOT BE INTERCHANGED**. Thus, with the first twisted pair, Supply + goes to Terminal 1 on the PCB and Connector respectively, and the Common Supply goes to Terminal 3 on the PCB and Connector respectively – and as detailed on page 21.
- 4/** The recommended cable is: Helkama REF-HF 4 x 2 x 0.5mm² - 4 Twisted pair) Nominal outside diameter of 11.5mm. Cut the fourth pair off.

4.6 WIRING FOR SYSTEM LAYOUT

A TRIPLEX™ system with 1 Sensor will always use Wiring Option 1.


For a TRIPLEX™ system with 2 or 3 Sensors there are 2 Wiring Options; either by running three cables independently directly to the Monitor, (as shown in schematic on Page 10) or alternatively, by utilising a 3-Way PCB installed in a Junction Box, (see schematic on Page 11.) This option would have the advantage of reducing the size of bulkhead penetrations for separate cables and the amount of cable needed.

For Wiring Option 2, QMI supply an unboxed 3-Way PCB for others to install.

WIRING OPTION 1 – With each Sensor wired individually


For 1, 2 or 3 Sensors where each Sensor has individual cables connected to the Monitor. All wiring connectors for the Atmospheric Sensors, alarms and power are on the Relay Board as shown below.

Relay Board with PSU (Part No. Q01T05)




4.6 WIRING FOR RELAY BOARD (Part No. Q01T05)

The Relay Board has the following connections:



4.7 WIRING OPTION 1: INDIVIDUAL WIRING FOR 1, 2 OR 3 ATMOSPHERIC SENSORS (Part No. Q10C) to TRIPLEX™ MONITOR (Part No. Q01T)





IMPORTANT NOTICE

Wiring of the TRIPLEX™ Monitor and Junction Box Terminal Blocks

1/ Please note that the six-way terminal connectors fitted to the Monitor and Sensors are numbered from left to right: 1, 2, 3, 4, 5, 6

2/ In order to show the twisted pair connections, the drawings have been drawn showing numbers running from left to right as: 1, 3, 2, 4, 5, 6

4.8 CABLE DETAILS FOR CONNECTION FROM ATMOSPHERIC SENSORS (Part No. Q10C) to TRIPLEX™ MONITOR (Part No. Q01T) RELAY BOARD (Part No. Q01T05)



NOTES:

The cable for the above is specified as HELKAMA, cable reference RFE-HF 0.5mm² 2 pair, with nominal o/d of 11.5mm.


If unavailable, use equivalent and connect twisted pairs to same terminations.





SOCKET

WIRING INFORMATION

SENSOR PCB (6 WAY)



4.9 CABLE DETAILS FOR CONNECTION FROM ATMOSPHERIC SENSORS (Part No. Q10C) to 3-WAY PCB (Part No. Q01T06)



NOTES:


The cable for the above is specified as HELKAMA, cable reference RFE-HF 0.5mm² 2 pair, with nominal o/d of 11.5mm.
If unavailable, use equivalent and connect twisted pairs to same terminations.




SOCKET

WIRING INFORMATION

SENSOR PCB (6 WAY)



4.10 WIRING DETAILS FROM TRIPLEX™ MONITOR (Part No. Q01T) to 3-WAY PCB (Part No. Q01T06) FOR 2 OR 3 ATMOSPHERIC SENSORS (Part No. Q10C)




IMPORTANT NOTICE

Wiring of the TRIPLEX™ Monitor and 3-Way PCB Terminal Blocks.

- 1/ Please note that the six-way terminal connectors fitted to the TRIPLEX™ power supply PCB are numbered from left to right: 1, 2, 3, 4, 5, 6
- 2/ In order to show the twisted pair connections, the drawings here have been drawn showing numbers running from left to right as 1, 3, 2, 4, 5, 6

4.11 WIRING DETAILS FROM THE 3-WAY PCB (Part No. Q01T06) TO 2 OR 3 ATMOSPHERIC SENSORS (Part No. Q10C)




IMPORTANT NOTICE

Wiring of the TRIPLEX™ Monitor and 3-Way PCB Terminal Blocks.

- 1/ Please note that the six-way terminal connectors fitted to the TRIPLEX™ power supply PCB are numbered from left to right: 1, 2, 3, 4, 5, 6
- 2/ In order to show the twisted pair connections, the drawings here have been drawn showing numbers running from left to right as 1, 3, 2, 4, 5, 6

4.12 ALARM OUTPUTS AND ALARM LEVEL WIRING

- 1/ The alarm outputs are transmitted from the Monitor to the Customers control system.
- 2/ The alarms operate via Open or Closed contacts (Relays).
- 3/ The following Alarms are fitted:
 - A. Early Warning Alarm
 - B. Fault Alarm
 - C. Functional Shutdown Alarm
 - D. Main Alarm
- 4/ Wiring one side of each block either open or closed requires a 6-core cable for 3 Alarms. Wiring both sides of each block requires a 9-core cable for 4 Alarms.
 Note: Cable core size should be of minimum 6 cores and can range from a minimum thickness of 0.25mm² up to 2.5mm² maximum.
- 5/ To close on Alarm, wire one core to NO and one core to C.
 To open on Alarm, wire one core to NC and one core to C.



Fan Failure must have a link between the first two points as shown

| | % ALARM LEVEL | LIGHTS DISPLAYED |
|------------------|---------------|---|
| | 0% to 79% | Green System Operational |
| | 80% to 99% | Amber (flashing) Early warning alarm and relay activated |
| | 100% | Red (flashing) Attention required (Plant will shutdown if wired) |
| Relays activated | 80% | Early warning alarm |
| | 100% | Alarm and plant shutdown |

4.13 TRIPLEX™ 4-20mA ANALOGUE DATA LOGGER OUTPUT – Optional (Part No. Q08-3)

The Data Logger function in Atmospheric systems is used for alarm panel integration or black box data recording. The data collected can be used to determine the cause of a build-up of oil mist towards a possible explosion and help find a solution.

The Monitor sends out a 4-20mA signal corresponding to the displayed mist percentage for each Sensor. This is a digitally calculated reading taking into account temperature non-linearity of the Sensors and oil deposit build-ups within the Sensor.


The signal can be used on a master alarm panel, or data logger and corresponds to the reading shown in the display.

$$\text{Current} = (\text{Display \%} \times 16 \div 156) + 4$$

| | | | | | | | | | | |
|----------------|------|------|------|------|------|------|-------|-------|-------|-------|
| Display | 0 | 10 | 20 | 30 | 40 | 50 | 60 | 70 | 80 | 90 |
| mA | 4.00 | 5.00 | 6.00 | 7.10 | 8.10 | 9.10 | 10.20 | 11.20 | 12.20 | 13.20 |

| | | | | | | | | | |
|----------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| Display | 100 | 110 | 120 | 130 | 140 | 150 | 160 | 170 | 180 |
| mA | 14.30 | 15.30 | 16.30 | 17.30 | 18.40 | 19.40 | 20.41 | 21.40 | 22.50 |

The 4-20mA data output from the Monitor is available on the 5-Way Connector on the bottom right of the Monitor as shown in the location of the Data Logger PCB image below. Cable must be 4-core with a diameter of 0.5mm²



Cable must be 4-core with a diameter of 0.5mm²

| HARTING PIN OUT | FUNCTION |
|-----------------|---|
| 1 | 1/0 |
| 2 | 2/0 |
| 3 | 3/0 |
| 4 | 12+ Volts |
| 5 | No connection should be made to this terminal |

SECTION 5

SETTING UP THE SYSTEM


- | | | |
|-----|----------------------------------|---------|
| 5.1 | Setting up Sensors | Page 34 |
| 5.2 | Changing the number of Sensors | Page 35 |
| 5.3 | Isolating or restoring a Channel | Page 36 |
| 5.4 | Test sequence | Page 37 |



5.1 SETTING UP SENSORS

The TRIPLEX™ Monitor can accommodate up to 3 Sensors simultaneously.

The number of Sensors is set using the DiP switch on the TRIPLEX™ PCB.



The Monitor is supplied set for Channel 1 unless otherwise requested.

When unused channels are selected the display will show a fault 'F1' and the lights will flash amber, green, red.


To change the channel number and cancel the original channel, the following procedure should be carried out:

- 1/ Disconnect the power to turn off the Monitor and switch off the system.
- 2/ For safety, unplug the 3-pin power connector from the Monitor.
- 3/ Using 'T' handled Allen key provided, unscrew 4 x M6 screws located at each corner of the Monitor.
- 4/ Open the enclosure to reveal the TRIPLEX™ PCB which is mounted on the inside of the display panel.
- 5/ The Binary switch blocks are located on the back of the MP3 PCB v3.2. There are a total of 10 Binary switchers and the Binary switch block is located as shown above.
- 6/ Reset the Binary switches (as required) as per the table on the following page.
- 7/ Replace the 3-pin power supply plug to the Monitor and restore the power supply at source.

5.2 CHANGING THE NUMBER OF SENSORS

The TRIPLEX™ system CMU can be set up for a different number of Sensors and can have a total of 3 Sensors connected to it.

The number of Sensors in use can be adjusted by resetting the Binary DiP switches located on the back of the MP3 Processor Board V3.2.



NOTES:

On the DiP switch shown here, Channels 1-2 are used to change the amount of Sensors.

Channel 5 changes the Oil Mist range.

Channels 3 and 6-10 are not used and should not be touched.

| SENSORS REQUIRED | SWITCH 1 | SWITCH 2 | SWITCH 3 | SWITCH 4 | SWITCH 5 | SWITCH 6 | SWITCH 7 | SWITCH 8 | SWITCH 9 | SWITCH 10 |
|------------------|----------|----------|----------|----------|----------|----------|----------|----------|----------|-----------|
| 01 | ON | OFF | OFF | OFF | SEE NOTE | OFF | OFF | OFF | SEE NOTE | OFF |
| 02 | OFF | ON | OFF | OFF | | OFF | OFF | OFF | | OFF |
| 03 | ON | ON | OFF | OFF | | OFF | OFF | OFF | | OFF |

NOTES:

Switch 5 is for the oil mist range:

- With Switch set to **OFF** the oil mist range is from 0 up to 1.30mg/L
- With Switch set to **ON** the oil mist range is from 0 up to 2.0mg/L

After changing the Switch from OFF to ON or ON to OFF, the alarm levels should be reset for each channel by placing the magnetic pen over the RESET circle, or by turning the key a quarter turn, and then back.

To read individual channels:

- 1/ Place the magnetic pen over the required channel 'Number Circle'
- 2/ The channel display will show the selected Channel Number
- 3/ The % display will show the % of oil mist density (of the pre-set alarm level)
- 4/ After one minute, the display reverts to the channel with the highest % of mist reading.

5.3 TO ISOLATE OR RESTORE A CHANNEL

If a Sensor becomes faulty and requires changing 'F3' will appear on the display and the green, amber and red display will flash.

As a temporary measure it is possible to isolate the Sensor from the Monitor panel, ('Isolate' in this instance is to remove the Sensor signal from the Monitor via the software.)

To carry out the 'Isolate Function', turn the security switch key to 'Settings' mode, place the magnetic pen on the 'Isolate' circle, then place it on 'Channel' number. Turn the key back to 'RUN' mode. The Channel/Sensor is now isolated and the display will now be blank. If the pen is placed over the 'Channel' number 'IC' will appear on the display.

After the Sensor has been replaced and/or the lens cleaned, the channel can be reinstated by turning the key to 'Settings' mode, place the magnetic pen on the 'Isolate' circle then on to 'Reset'. Finally, place the magnetic pen on to the 'Channel' number and turn the security key to operating mode. This will put the channel and associated Sensor back online.

5.4 TEST SEQUENCE

Before beginning the Test Procedure, inform the control room or area supervisor.

To activate the test procedure make sure the security key is turned to running mode then place the magnetic pen over the circle marked 'TEST'. The sequential testing system will commence as follows:

- 1/ Testing indicators will illuminate the Software Version – 1.03.
- 2/ The running (green), anticipatory (amber) and alarm (red) indicators will illuminate in sequence.
- 3/ All digital readouts will indicate '8'.
- 4/ All digital readouts will then indicate '111' showing that all segments of the numerical display are working with no fade.
- 5/ Each Sensor lens will be indicated. (**NOTE:** 'Cd' indicates clean lens.) When 'dd' (dirty lens) appears on the display, Sensor lenses are under 80% clean. In this instance refer to Lens Cleaning Instruction; Section 6.2.) When dirty, 'F2' will automatically show on the display. If ignored it will go to 'F3'.
- 6/ All external relays, with the exception of the of the shut down relay, will operate for 10 seconds. If the system has an audio alarm system, it is recommended that personnel should be warned of the impending test. The test includes a test of the fault monitoring circuit, i.e. watchdog, when 'F9' will appear momentarily. In the event of a CMU failure 'F9' will be display continuously. In this case the PCB Relay Board must be replaced.
- 7/ After the relays have been tested the CMU will automatically return to display the channel with the highest concentration of oil mist.
- 8/ **NOTE:** After 'Power On' or 'Reset' procedures are implemented, the relay outputs are inhibited for 60-120 seconds in the event of an alarm. This must be noted if smoke testing is carried out on a Sensor.
- 9/ **NOTE:** When using the self-test facility, the display will show the condition of the Sensor, i.e. 'dd' (the lens is dirty) or 'Cd' (the lens is clean). **HOWEVER, TWO FULL MINUTES SHOULD ELAPSE BEFORE USING THE SELF-TEST FACILITY AGAIN.** This is to allow the software to latch back into the correct running mode, otherwise erroneous signals may be displayed. During this sequence isolated Sensors may be displayed 'Cd'. Should any function throughout the sequence fail to operate as specified, please refer to the Fault Finding Section and Directory, Section 6.6, Pages 48-49.

SECTION 6

OPERATING THE SYSTEM

| | | |
|-----|--|-------------|
| 6.1 | TRIPLEX™ Pre-Power on Check | Pages 40-42 |
| 6.2 | Operating | Page 43 |
| 6.3 | Setting and Changing Alarm Levels | Page 44 |
| 6.4 | Operation of Alarm Relays | Page 45 |
| 6.5 | Response to an Alarm | Pages 46-47 |
| 6.6 | Fault Directory | Pages 48-49 |
| 6.7 | Fuses | Page 50 |
| 6.8 | Security Key Switch | Page 50 |
| 6.9 | Transistors TR1, LEDs and Fuses on PCB | Pages 51-52 |



6.1 TRIPLEX™ PRE POWER-ON CHECK

It is important to perform the following test BEFORE powering on the Triplex Monitor.

Disclaimer: If this testing is not performed your processor board will fail prematurely and will not be covered under Warranty as we know the TR1 Resistor will fail within the first 12 months unless the test is conducted. We do include a spare TR1 Resistor in the Maintenance Kit to fix the issue.

To perform this test you will need the following equipment:

- 1/ A Multimeter capable of 200Ω for taking resistance readings
- 2/ A M4 Hex Allen Key
- 3/ Pen and paper to record readings

The Monitor does not require power for this test.

Open front panel of the monitor by using the M4 Hex Allen Key to unscrew all 4 outer edge screws. (Note that they will not come all the way out as they are fixed in place with 'o' rings.) Once the screws are loosened, open the Monitor panel outward towards hinged edge.



Taking your Multimeter turn the dial to the 200Ω setting.

6.1.1 WIRING ISSUE INDICATORS

First, turn your Multimeter dial to the 200Ω setting.

Before we start there are two indicators of wiring issues:

- 1/ Once the probes are connected, if your Multimeter is reading 0 there is a short in the wiring
- 2/ Once the probes are connected, if your Multimeter is reading 1 there is a loose connection in this channel connector.

6.1.2 Test

To complete this test, place the positive probe in Pin 6 as shown in the image and place the negative probe on the brown wire on Pin 1 on the door of the Monitor.



You will need to take a reading for each channel in use from the connector on the door of the Monitor.

- 1/ Start with the brown wire on Pin 1
- 2/ Then go to the red wire on Pin 2
- 3/ Then the orange wire on Pin 3

You should note a reading for each channel in use.

The readings for each channel that is connected would be:

Test

1/ Channel 1: 34-39k

2/ Channel 2: 34-39k

3/ Channel 3: 34-39k

Anywhere out of these ranges on a channel would indicate a fault.

To confirm that these tests have taken place, please use the online form at:
triplex-system-pretest@oilmist.com with the following key information:

1/ TRIPLEX™ Monitor Serial Number

2/ Sensor Serial Numbers

3/ Test readings for each Sensor/Channel

You will need to complete this information in order to VALIDATE YOUR WARRANTY.

Further tests are available should the above Tests fail to provide the correct readings. For any further clarification please email: qmi@oilmist.com




6.2 OPERATING

A sample of air is continuously drawn through each Sensor and the level of oil mist density is monitored. This process is continuous at each Sensor. The signals are fed to the micro-processor which is located in the Monitor.

The signals are scanned at 500 millisecond intervals and the data is presented as a digital display reading from 0% to 100% of alarm level.

Although oil mist samples are measured in mg/L the reading per channel is presented as a percentage of the alarm setting.

6.2.1 RELAY AND LED CHART

| | % ALARM LEVEL | LIGHTS DISPLAYED |
|------------------|---------------|---|
| | 0% to 79% |  Green System Operational |
| | 80% to 99% |  Amber (flashing) Early warning alarm and relay activated |
| | 100% |  Red (flashing) Attention required (Plant will shutdown if wired) |
| Relays activated | 80% | Early warning alarm |
| | 100% | Alarm and plant shutdown |

6.2.2 OPERATING RANGES

0 – 1.30mg/L

0 – 200mg/L

As a percentage of the alarm setting


6.3 SETTING AND CHANGING ALARM LEVELS

The QMI TRIPLEX™ is pre-set. However, should the settings require adjustment and the alarm level set lower, then follow the procedure outlined below.


Normal setting for atmospheric systems should be as low as possible, say 0.04 to 0.05mg/L. This is so that once oil mist starts to form it will be detected as soon as possible.

During the setting-up procedure normal operation of the CMU is disabled, therefore, to set and change alarms levels follow this procedure:

- 1/ With the security key supplied (Part No. Q0103), release the security switch, which is fitted to prevent un-authorized adjustment of the system.
- 2/ Turn the key clockwise. The light above 'Setting' will illuminate.
- 3/ Place the magnetic pen (Part No. Q0109) flat against the circle marked 'Alarm Levels'.
- 4/ Place the magnetic pen flat against the 'Raise' Alarm Level circle marked with a '+' or the Lower Alarm Level marked with a '-'. Raise or lower the level, each time removing the pen away from the circle for each increment of Oil Mist until the required level is reached. The level will be indicated on the digital 'Reading'.
- 5/ Place the magnetic pen flat against the circle marked 'Channel Number' to set that channel to the level indicated at the digital reading.



- 6/ To set another channel repeat steps 4 and 5.
- 7/ When setting is complete turn the key anti-clockwise. This locks the system, then remove the key.
- 8/ Now the system is locked, it is possible to check the settings by placing the pen on 'Alarm Level' then on 'Channel Number'. The new set level will then be displayed.
- 9/ To reset any channel ALL the above items MUST be repeated.



6.4 OPERATION OF ALARM RELAYS

The relays work in conjunction with the lights on the Monitor display panel:

6.4.1 MINIMUM ALARMS

The minimum alarm relays that are required to be wired are the **Main** alarm and the **Fault** alarm.

In addition, there are two other alarm relays available within the Monitor; the **Shutdown** alarm relay and the **Early Warning** alarm relay.

The Shutdown alarm relay is activated at 100% of alarm setting.

The Early Warning alarm relay activates at 80% of alarm setting and is used as an early warning alarm. (With an Atmospheric Oil Mist Detection system this will be in the 'blink of an eye' if the system is set correctly.)

6.4.2 FAULT ALARM

A fault alarm relay is completely divorced from the other relay systems and is only activated after a fault has developed in the Oil Mist Detection System. No relays will activate for 2.5 seconds, as the Monitor will check first that the fault is in the system and not a problem with the environment.

Even when the fault alarm relay is activated the instrument goes on monitoring unless there is a major malfunction of the Monitor or Sensor. Information is also being continuously given as a digital display of the highest concentration of oil mist and its location.

The digital display will always indicate the channel (i.e. area) with the highest level of oil mist. **IN THE EVENT OF A FAULT ALARM IT WILL BE THE FIRST CHANNEL TO GO INTO THE FLASHING GREEN, AMBER OR RED CONDITION THAT IS INDICATED ON THE DISPLAY (F1, F2 and F3).**

NOTE: THERE IS A TWO MINUTE DELAY when the fault alarm sounds. After a self-test or a channel check the display will always revert to the channel with the highest oil mist level reading.

6.4.3 ALARM OPERATING RANGES

With Binary switch 5 set to OFF the alarm operating range is from 0 up to 1.30mg/L.

With Binary switch 5 set to ON the alarm operating range is from 0 up to 2.00mg/L.

6.5 RESPONSE TO AN ALARM

There are two stages of oil mist indication:

1 ANTICIPATORY/EARLY WARNING

At 80% the light will assume a 'flashing' mode.

The channel number will be indicated, and the digital reading will indicate the percentage density of the pre-set mist alarm level. The early warning alarm relay will operate.

NOTE: This alarm is automatically operated when the oil mist density level reaches 80% of the pre-set alarm level.

2 FULL ALARM

At 100% of alarm level the red indicator will flash indicating that the oil mist level is above the pre-set alarm level. The offending channel will be displayed alongside the digital read-out level. The functional shutdown relay alarm RL9 will operate if wired into the system. At this level, RL10, the main alarm, will be activated. Further action should be taken in accordance with standard procedures.

Over-riding the QMI TRIPLEX™ system during procedures that may introduce particles into the atmosphere (e.g. painting) is at the operator's discretion. If such a function is required it should be incorporated into the overall operating system.

IMPORTANT: When any alarm sounds all personnel should leave the area.

IMPORTANT NOTICE:

With Atmospheric Oil Mist Detection Systems, the alarm point should be set quite low so that the Main Alarm activates as soon as there is any Oil Mist sensed in the Atmosphere.

The Oil Mist level will increase so quickly that the Early Warning and Main Alarm will activate almost simultaneously.

The Early Warning Alarm would normally be used in Engine Crank Case Oil Mist Detection systems where the Oil Mist usually increases more slowly.

6.5.1 FAULT ALARMS

The fault alarms indicate if there is any fault in the monitoring system. The Monitor faceplate has a list of the fault alarms and their significance. This uses relay RL8. See table below for the fault conditions as presented on the Monitor faceplate. For more information see the Fault Directory on the following pages.

| CHANNEL | READING | RESPONSE |
|---------|---------|---|
| 1-3 | F1 | Check and repair relevant cable |
| 1-3 | F2 | Clean Sensor according to instructions |
| 1-3 | F3 | Clean Sensor Check Sensor fan Replace Sensor See Fault Directory – Section 6.6 |
| C | IC | Channel isolated |

If “No CPU” light is on, there is a processor fault.

‘dd’ on test indicates when the Sensor lens are dirty so it is necessary to clean them.

‘cd’ on test indicates when the Sensor lens are clean.

6.6 FAULT DIRECTORY

| FAULT | ACTION | REMEDY |
|---|---|---|
| F1 on display and channel number shown | <p>1- Make up a short lead with 6-pin female connector supplied with the Sensor</p> <p>2- Unplug and unwire Sensor with F1 error from junction box channel numbers on PCB, then wire to short lead you made in step 1</p> <p>If the display becomes steady this confirms there is a fault in the cable between the Monitor and Sensor</p> | <p>Check the cable is earthed between the Monitor and Sensor. Check there are NO OTHER earth leads, or copper earth trips as these will give interference</p> <p>If the F1 error is resettable there is an issue with the wire from the Sensor to the Junction Box If this does not correct the issue you have a wiring issue on the cable from the Monitor to the Junction Box Please refer to wiring diagrams – Section 4</p> |
| F1 and Sensor number is displayed | Check cable between Monitor and Sensor | F1 denotes cable fault Check for split or damaged cable or incorrect earthing – see wiring instruction |
| F1 and all Channel lights flash | Check Fuse FS1 on the Power Supply Board See Section 4.6 on pages 24–25 | If the fuse has failed replace it with a 1.25A fuse If the fuse fails again, check complete wiring of the system for short-circuits or damaged wires |
| F1 and all Channel lights flash | Check the Fuse FS1 on the Power Supply Board See Section 4.6 on pages 24–25 | If the fuse is OK, then TR1 should be replaced |
| F2 | Remove Sensor Clean lens See Section 7.2 on page 55 | If a Sensor needs frequent cleaning investigate source of dirt |
| F3 and Sensor number is displayed | Check Sensor lens | <p>1. Take Sensor off</p> <p>2. Clean lens</p> <p>3. Replace Sensor</p> <p>If F3 still shows, return Sensor to QMI for repair. Isolate channel if there are no spare Sensors</p> |
| F3 and Sensor number is displayed LED on front of the Sensor flashes RED | Check Sensor fan | <p>Isolate and remove Sensor</p> <p>Replace fan (Part No. Q1004) following instructions supplied – see Section 7.3 on page 57</p> |

6.6 FAULT DIRECTORY

| FAULT | ACTION | REMEDY |
|---|--|---|
| Fault alarm comes on. QMI Monitor shuts down and display ceases | Check FS3 fuse on side of the Monitor above security key | 3.15A anti-surge fuse may have failed due to an internal fault in the Monitor. Check FS3 fuse (Part No. Q0115) in the Monitor |
| Fault alarm comes on. QMI Monitor shuts down | Check FS3 fuse on side of the Monitor above security key | If fuse is OK check external power supply to QMI system. Fault alarm (will sound) if power is shut down |
| 'No CPU' light on | Check internal connectors | The CPU light indicates a fault on TRIPLEX™ Relay Board This board is either carried as a spare or is ex-stock QMI |
| LED 1 on Relay Board not flashing | Check fuse FS1 | Change failed fuse FS1 – 1.25A anti-surge fuse (Part No. Q0114) |
| LED 1 for TR1 does not light | FS1 fuse blown | Replace FS1 with 1.25A anti-surge fuse. If the fuse keeps failing, then check wiring and Sensor for faults. |
| | TR1 Faulty | Replace TR1 (Part No. Q0111) with spare in Maintenance Kit. (Take care not to short TR1 during soldering.) |
| LED 2 does not light | FS2 fuse blown | Replace FS2 with 400mA anti-surge fuse (Part No. Q0112) If LED light still does not light, check for fault in PSU. See Section 4.6 on pages 24-25 |
| On start up of the system Monitor the display is erratic and does not settle down | Check if cable is screened | If cable is screened, check that the screen is connected to Pin 5 at both ends of the cable. Make sure the braid or drain wire does not come into contact with other terminals at either end of the cable. If cable is not screened, check to see if cable runs near any electrical power source. If it does, cover cable in steel conduit. There is no need for extra earthing, however the screen needs to be connected to Pin 5 at both ends. |

6.7 FUSES

There are two fuses on the TRIPLEX™ Relay Board (see page 24) and one on the outside of the Monitor.

FS1 (Part No. Q0114) is a 1.25A fuse. This is connected to TR1 and is the supply to the Sensors.

The LED continually flashes in operation.

FS2 (Part No. Q0112) is a 400mA fuse for 12V power supply to the fan. The LED is permanently lit in operation.

FS3 (Part No. Q0115) is a 3.15A fuse (in a holder) fitted to the side of the Monitor.

6.8 SECURITY KEY SWITCH (Part Nos. Q0103 or Q0103L)


Only one security key is required to make system changes, (alarm settings, isolating channels etc.) and this key should be kept securely at the discretion of the operator. It is possible to check the settings without using the security key switch. (Part No. Q0103)

When key is in HORIZONTAL position = LOCKED mode

When key is in VERTICAL position = SETTING mode

NOTE: The Monitor does not have an on/off switch this is to prevent the oil mist Sensors from being switched off. To turn off the power disconnect the power supply.

6.9 TRANSISTOR TR1, LEDS AND FUSES ON PCB (Part No. Q01T05) - LAYOUT



NOTES:

If LED 1 is not flashing and you have checked the fuse is OK, it could be that TR1 is faulty. You should then check the system for wiring faults or shorts. If you are satisfied that the system is OK, TR1 (Part No. Q0111) can be replaced using the replacement from the Maintenance kit.

LED 1 will flash when 12V power is being supplied to the Sensor heads. If LED 1 is not flashing then fuse FS1 has failed. It needs to be replaced with a 1.25A fuse. (Part No. Q0114)

If FS1 continues to fail, check system for faults in wiring or a faulty Sensor.

LED 2 will light continuously when 12V is being supplied to the Q07 Junction Box PSU failure on atmospheric systems. If LED does not light then fuse FS2 may have failed. Check wiring for faults, then replace FS2 fuse with a 400mA fuse. (Part No. Q0112)

6.9 TRANSISTOR TR1, LEDS AND FUSES ON PCB (Part No. Q01T05) LAYOUT

FS3 (Part No. Q0115)

Is a 3.15A fuse (in a holder) fitted externally to the side of the Monitor.

This image shows the internal location on the Relay Board. See Section 4.6 on page 24.



SECTION 7

MAINTENANCE

| | | |
|-----|------------------------------|-------------|
| 7.1 | Maintenance Procedure | Page 54 |
| 7.2 | Lens Cleaning Procedure | Pages 55-56 |
| 7.3 | Replacing Fan in Sensor | Page 57 |
| 7.4 | Maintenance Kit | Pages 58-59 |
| 7.5 | Suggested Maintenance Plan | Page 59 |
| 7.6 | Replacement Parts and Spares | Pages 60-61 |



7.1 MAINTENANCE PROCEDURES

The QMI TRIPLEX™ incorporates an operational fault-finding system, which will identify operational and component breakdowns. During operational breakdowns, a fault code is displayed against the relevant Sensor number. The possible fault codes are listed on the Monitor front plate.

In the event of a component breakdown or fault, the CPU light will come on, see Fault Directory, section 6.5.

With all fault indications the fault warning relay is non-energised. The relay may be returned to normal through the 'RESET' function. The warning light on the digital display will persist until the fault is corrected or the channel isolated.

7.1.1 SENSOR CLEANLINESS

A large percentage of returns under Warranty are in fact due to dirty lenses. Very often, due to difficult working conditions and lack of experience, the lenses in the Sensor are not properly cleaned. This problem is made more difficult because the operator has to return to the Monitor in order to check the cleanliness of the lenses. Before sending back any Sensors run the test program and if you see 'dd' on any channel this means the detector is dirty.

If this is the case, read the cleaning process outlined in section 7.2.

NOTE: IT IS HIGHLY RECOMMENDED THAT A CLEAN AND WORKING SPARE SENSOR BE INSTALLED WHILE CLEANING A SENSOR.

7.1.2 REPLACING SENSOR FAN (Part No. Q1004)

The Monitor will indicate when there is a Fan Fault and F3 will appear (See Fault Directory section 6.5.)

To replace the Fan see section 7.3 on page 57.






7.2 LENS CLEANING PROCEDURE

The 'F2' Fault indicates need for lens cleaning on the relevant channel on the TRIPLEX™ Monitor (Part No. Q01H).

It is advisable to have a clean and working spare Sensor. (Part No. Q10)

To clean the lenses in the event of oil or condensation build up, use the following guidelines:

1/ Isolate the relevant channel on the Monitor:

-  Turn Security Key to Setting Mode
 -  Using Magnetic Pen
 -  Touch Isolate Button
 -  Touch Channel Button
-  Turn Security Key back to Working Mode.

2/ Unplug cable from Sensor.

3/ Holding the Sensor, undo the 4 screws fixing the Sensor body to the Articulated Joint. Use the Allen Key (Part No. Q1007) tool from the Maintenance Kit.

4/ Replace with a spare Sensor, if available. Proceed to item 8.

5/ In a clean area, remove cover plate by undoing the 4 Button Head Screws. The tool is in the Maintenance Kit.






6/ 3 lenses will be visible inside the chamber. Using a clean cloth, clean the lens with Isopropyl alcohol to wipe the lenses clean. For badly contaminated lenses, repeat until clean. Polish the lenses with a clean and dry cloth.

DO NOT SATURATE THE LENSES WITH FLUID.

7/ Ensure the chamber is dry. Replace the cover plate.

8/ Replace Sensor on Articulated Joint. Make sure Sensor is in original position.

9/ Reset the Sensor on Monitor:

-  Turn Security Key to 'Settings' Mode
 -  Using Magnetic Pen
 -  Touch 'Isolate' Button
 -  Touch 'Channel' Button
-  Turn Security Key back to Working Mode.

SEE IMPORTANT NOTES OVERLEAF

IMPORTANT NOTES

- 1 /** The Sensor electronics are factory calibrated and cannot be serviced on site. In the event of a fault the Sensor must be sent back to QMI unless it is a faulty Fan, in which case change the Fan as shown in section 7.3.
- 2 /** DO NOT USE diesel oil, acetone or kerosene to clean Sensors or Sensor lenses.
- 3 /** DO NOT IMMERSE Sensor in any cleaning solution.

A VIDEO SHOWING THE CLEANING PROCEDURE CAN BE FOUND AT:


<https://www.oilmist.com/how-to-clean-qmi-q10-sensor>

The following QR code can also be used to access the video:



7.3 REPLACING FAN (Part No. Q1004) IN SENSOR

- Remove lid by taking out the four countersunk Allen screws using the 2.5mm Allen key (Part No. Q1007).
- Remove RED and BLACK wires from fan failure terminal block.
- Remove four buttoned Allen screws holding fan to air sensor using the 2.5mm Allen key.
- Fit new fan by replacing four button-head screws. Check direction arrows on the fan.
- Fit RED wire to the \pm terminal of fan failure terminal block.
- Fit BLACK wire to the \pm terminal of fan failure terminal block.



ADJUSTING FAN FAILURE ON SENSOR – (Part No. Q1004)

- 1/ Turn the potentiometer screw fully anti-clockwise (15 turns).
- 2/ Connect Sensor to Monitor. The LED on the front of the Sensor will flash **GREEN**.
- 3/ Allow 2 minutes before adjusting, by this time the LED should be **AMBER** with a **RED** pulse.
- 4/ Slowly turn the potentiometer clockwise until the LED turns to a steady **GREEN**.
- 5/ When the LED is showing steady GREEN, turn the same potentiometer a further quarter turn clockwise.
- 6/ Test for fan failure operation by gently stopping the fan with your finger.
- 7/ Check that the LED flashes **RED**.
- 8/ Refit Sensor lid using the four countersunk Allen screws, ensuring red and black wires are not trapped.
- 9/ Wait for two minutes and ensure LED remains constant **GREEN**.
- 10/ Installation of the fan (Part No. Q1004) is now complete. Refit Sensor in chosen position.

7.4 MAINTENANCE KIT



To assist with ongoing maintenance of our Oil Mist Detection systems, there is a QMI Maintenance Kit available.

This kit has most of the tools necessary in order to maintain the systems functionality. The following items included in the Maintenance Kit are shown below.



| PART NO. | QMI PRODUCT | DESCRIPTION | PHOTO |
|----------|--|---|---|
| Q1004 | Replacement Fan | For Q10 Sensor – includes fixing screws |  |
| Q0208 | Replacement Socket | 6-Pin Bulgin Socket for Sensor |  |
| Q1007 | M2.5 Hexagonal Allen Key | For Sensor lid, inspection cover and fan |  |
| Q1008 | M3 Hexagonal Allen Key | For Articulated Joint | |
| Q0113 | M4 Hexagonal Allen Key | To open Monitor lid | |
| Q0103 | Monitor Security Key For serial numbers up to T623 | For changing settings on TRIPLEX™ Monitor Q01T |  |
| Q0103L | Monitor Security Key For serial numbers from T624 onwards | For changing settings on TRIPLEX™ Monitor Q01T |  |
| Q0213 | Cotton Buds | For cleaning Q10 Sensor lenses. (Approximately 100 buds per pack.) |  |
| Q0109 | Magnetic Pen | To activate displays on Monitor |  |

7.4 MAINTENANCE KIT

| PART NO. | QMI PRODUCT | DESCRIPTION | PHOTO |
|----------|-----------------------------------|--|---|
| Q0111 | TR1 Transistor | TR1 Transistor for Q01T05 Relay Board |  |
| Q0112 | 400mA Anti-Surge Fuse (Pack of 5) | For FS2 on Relay Board For FS3 Data Logger Protection |  |
| Q0114 | 1.25 Amp Fuse (Pack of 5) | For FS1 on Relay Board | |
| Q0115 | 3.15 Amp Fuse (Pack of 5) | For FS4 on side of Monitor | |

Please Note: QMI recommends IPA (Isopropyl Alcohol) to clean the Sensor Lenses. The product "Clean All" is no longer available.

It is also recommended that a spare Sensor (Part No. Q10) is purchased.

7.5 SUGGESTED MAINTENANCE PLAN

The only regular operation that can be built into a planned maintenance of QMI equipment is to clean the lenses, but only when a manual test programme is initiated on the Monitor and on a weekly basis. (In service, this time interval should be decided by the system operator after gaining experience of cleaning routines depending on the environmental conditions the system is operating in.)

If, on doing the manual test, the Monitor indicates 'dd' on any channel this means you have 20% dirt on the lenses, in which case it is a good idea to clean as soon as it is feasible. (Note that the system can, however, compensate for up to 40% contamination of dirt on the lenses.)

The process for cleaning Lenses is shown in section 7.2 on page 53.

7.6 REPLACEMENT PARTS AND SPARES - QMI Codes

| CODE | QMI PRODUCT | DESCRIPTION |
|------------------|------------------------------|---|
| Q01T | TRIPLEX™ Monitor | Monitor, supplied with blind grommets |
| Q01T02 | Manual | Installation and Operation Manual |
| Q01T08 | TRIPLEX™ MP3 PCB for Monitor | For Monitor Processor Board version 3.2 |
| Q01T05 | PSU mounted on Relay Board | Fitted with switch mode Power Supply Unit (PSU) and PSU case |
| Q01T06 | 3-Way PCB - unboxed | For optional wiring using a Junction Box |
| Q1005 | Maintenance Kit | To assist with ongoing maintenance of QMI equipment – see Section 7.4 |
| Q0103 and Q0103L | Monitor Security Key | Security Switch to change settings |
| Q0106 | Switch Mode Power Supply | No case, for Power Supply Unit for Monitor |
| Q0109 | Magnetic Pen | To activate displays on Monitor |
| Q0111 | TR1 Transistor | Relay Board of Q01T Monitor |
| Q0112 | 400mA Anti-surge Fuse | For FS2 on Relay Board For FS3 Data Logger Protection (Pack of 5) |
| Q0113 | M4 Hexagonal Allen Key | To open Q01T Monitor lid |
| Q0114 | 1.25 Amp Fuse | For FS1 on Relay Board (Pack of 5) |
| Q0115 | 3.15 Amp Fuse | For FS3 on side of Monitor (Pack of 5) |

7.6 REPLACEMENT PARTS AND SPARES - QMI Codes - Continued

| CODE | QMI PRODUCT | DESCRIPTION |
|-------|------------------------------------|---|
| Q10 | Atmospheric Sensor | With Integral Fan |
| Q10C | Atmospheric Sensor Complete | With integral Fan, Mating Connector and Articulated Joint |
| Q1004 | Replacement Fan with Fixing Screws | For Sensor, including fixing screws |
| Q0208 | Replacement Socket | For Sensor, 6 Pin Bulgin Socket |
| Q1007 | M2.5 Hexagonal Allen Key | For Sensor lid, inspection cover and fan |
| Q1008 | M3 Hexagonal Allen Key | For Articulated Joint on Sensor |
| Q0213 | Cotton Buds | For cleaning Sensor (approximately 100 per pack) |

SECTION 8

RETURNS PROCEDURE

RETURNS PROCEDURE

Page 64

CONTINUOUS SUPPORT

Page 65

PRODUCT REGISTRATION

Page 66



GUARANTEE STATEMENT: Sensors returned for service or repair will be guaranteed for 12 months.

Please ensure these instructions are followed:

1/ The equipment being returned has a report with it stating the fault with the equipment; listing the fault number shown on the Monitor; the Serial No. of the Monitor (which is on the Monitor front plate); and the Serial No. of the Sensor, (which is on a sticker inside the front louvre and inside the PCB box). The equipment must be returned CLEAN and intact.

2/ The equipment must have a Manifest/Packing Note stating shipment contents.

3/ The equipment must include a note to advise QMI of who to contact to arrange Purchase Order and Shipping Instructions.

4/ The above documentation should be emailed to QMI in London:

Email: qmi@oilmist.com

5/ Dispatch the retained goods to:

Attention: QMI Repair Manager

Quality Monitoring Instruments Ltd

C/o Cambertronics Ltd

Unit 12, Manfield Park, Guildford Road, Cranleigh, Surrey GU6 8PT

Please ensure that you have included the information and documents in your email to QMI to request repair of equipment. Providing this information will increase the speed at which we can repair and return the goods.

CHECKLIST

- | | |
|---|--|
| <input type="checkbox"/> Fault Report included/attached | <input type="checkbox"/> Monitor Serial Number |
| <input type="checkbox"/> Fault Number Displayed F1____F2____F3____ | <input type="checkbox"/> Sensor Serial Number |
| <input type="checkbox"/> Equipment is clean | |
| <input type="checkbox"/> Numbered Purchase Order – with invoice and return address (Emailed and included) | |
| <input type="checkbox"/> Manifest / Packing Note - of shipping contents (Emailed and included) | |
| <input type="checkbox"/> Name of Contact person email address, telephone number and fax number | |

CONTINUED SUPPORT

In order to provide you with effective support for your equipment, please complete the Request for Information Sheet below and return to QMI.

QMI TRIPLEX™ ATMOSPHERIC OIL MIST DETECTION SYSTEM

If you would take the time to provide us the information outlined below it would help us respond more quickly to any questions or problems you might have with QMI equipment in the future.

NAME OF VESSEL/OR SITE: _____

LOCATION OF SYSTEM: _____

SERIAL NUMBER OF MONITOR: _____

NUMBER OF SENSORS: _____

SERIAL NUMBERS OF SENSORS: A _____ to A _____

EMAIL ADDRESS: _____

RETURN ADDRESS FOR EQUIPMENT: _____

If you have a technical problem, please contact us on the following:

Email: qmi@oilmist.com

Should you need to return equipment for service or repair, please see details on the previous page of this manual to see how the equipment should be returned.

PRODUCT REGISTRATION

In order to validate the warranty on your product, please complete the Product Registration form which can be found via this link.

THE PRODUCT REGISTRATION FORM CAN BE FOUND AT:

<https://www.oilmist.com/product-registration>

The following **QR code** can also be use to access the Form:



When completed please return this form by email to qmi@oilmist.com.



QUALITY MONITORING INSTRUMENTS LTD

T: +44 (0) 20 7328 3121

E: qmi@oilmist.com

W: www.oilmist.com

A: 4 East Barnet Road, London EN4 8RW

